

Guide for the **ADI Power Studio** Software Used with the **ADM1260** Super Sequencer IC

FEATURES

- Designed for configuring and monitoring **ADM1260** devices
- Reduces design complexity of multiple **ADM1260** devices, especially when multiple devices are presented as one virtual sequencer
- Provides both tabular and graphical views for device and rail settings
- Provides a quick setup wizard for easy project creation
- Provides an online debug feature combined with an SMBus jump command
- Support for monitoring rail voltages and status in online mode
- Support to manage and check the **ADM1260** black box records
- Create projects based on connected devices
- Operation for both online and offline mode to allow project generation and editing with or without hardware attached
- Detachable GUI windows for use with multiple monitors
- Provides simple and easy access to the **ADM1260** internal registers

APPLICATIONS

Evaluating, configuring, and programming the **ADM1260**

SOFTWARE PACKAGE CONTENTS

- ADI Power Studio** software
- USB-SDP-CABLEZ** driver
- Total Phase Aardvark driver

SOFTWARE REQUIREMENTS

Windows XP or higher

GENERAL DESCRIPTION

This user guide describes how to use the **ADI Power Studio**™ Graphical User Interface (GUI) with the **ADM1260** Super Sequencer IC®. The **ADI Power Studio** GUI is a software tool that offers a simple way to configure the sequencing and monitoring of a power system when using the **ADM1260**. The **ADI Power Studio** GUI gives the user full control to configure the sequencing and monitoring of a power system with up to 10 power rails on a single **ADM1260** or up to 40 rails when using several **ADM1260** devices connected together on the high speed interchip bus (ICB), featured on the **ADM1260**. Using the **ADI Power Studio** GUI, the operation of the ICB is transparent to the user, making multiple **ADM1260** devices appear to operate as a single virtual sequencer on the GUI.

TABLE OF CONTENTS

Features	1	Properties	19
Applications.....	1	Configuring the Input Ports	21
Software Package Contents	1	Setting the VXx Monitor Channels	21
Software Requirements.....	1	Setting the VPxx Monitor Channels.....	23
General Description	1	Setting the VH Monitor Channels	25
Revision History	2	Setting up a Sequence	27
Installing the ADI Power Studio GUI Software.....	3	Using the Black Box	38
Setting Up the Hardware	5	How to Add Black Box Functionality.....	38
Launching the ADI Power Studio GUI.....	6	How to Use the Black Box.....	39
GUI Operational Modes.....	6	Black Box Viewing Options	41
The ADI Power Studio GUI Welcome Tab.....	6	Black Box Erase Function	41
How to Generate a Basic Sequencing Project.....	8	Using the Register View.....	42
Starting a New Sequencing Project.....	8	How to View the ADM1260 Registers	42
Configuring the ADM1260 Hardware	11	Pin Settings.....	43
Control and Monitoring Assignment	14	Pin Settings View.....	44
Configuring the Outputs and Inputs of the ADM1260	18		

REVISION HISTORY

4/16—Revision 0: Initial Version

INSTALLING THE ADI POWER STUDIO GUI SOFTWARE

To begin designing with the **ADI Power Studio** GUI software, download a copy of the **ADI Power Studio** GUI from the **ADM1260** product page.

After the **ADI Power Studio** GUI file downloads, install the software by running the downloaded **ADI Power Studio v0.x.x.x Setup.exe** file.




Figure 1. ADI Power Studio Setup File

After the installation process begins, a dialog box appears, prompting the user to choose whether or not to allow the software to make changes to the computer. Click **Yes** to proceed with the installation of the GUI software.

After allowing the installation to proceed, the **ADI Power Studio Setup: License Agreement** dialog box appears, shown in Figure 2.



Figure 2. Analog Devices Software License Agreement

After reading the Analog Devices Software License Agreement, click the **I Agree** button to continue the installation process.

Next, the **ADI Power Studio Setup: Installation Options** dialog box appears, prompting the user to select which software components to install (see Figure 3). Different dongle drivers and a **Create Start Menu Shortcuts** option can be selected depending on user preference and system requirements; the Total Phase Aardvark driver, which comes in the software package, can be used with the **ADM1260**. However, for this example, select the **USB-SDP-CABLEZ Driver** for the dongle that connects to the **ADM1260** to communicate with the **ADI Power Studio** GUI and click the **Next** button. For more details about the **USB-SDP-CABLEZ** dongle, refer to the **EVAL-ADM1260EBZ** evaluation board user guide.




Figure 3. Selecting Components to Install

After selecting which components to install, the **ADI Power Studio Setup: Installation Folder** dialog box prompts the user to choose a destination folder for the installation of the **ADI Power Studio** GUI software. The user can change the destination folder to a different location by clicking the **Browse** button and search for the desired folder location, as shown in Figure 4.




Figure 4. Selecting a Location for the ADI Power Studio Software

After the installation folder is selected, click the **Install** button to continue. Then, the drivers for the previously selected hardware dongle install (see Figure 5).




Figure 5. Installing the ADI Power Studio Software Drivers

Click the **Next** button to continue installing the driver (see Figure 6).




Figure 6. Welcome Dialog Box

The default destination folder then displays. Click the **Install** button to continue (see Figure 7).




Figure 7. Choosing the Installation Location

A dialog box with a progress bar shows the progress of the dongle driver installation process (see Figure 8).




Figure 8. Dongle Driver Installation Process

After the driver setup completes, click the **Close** button to continue with the installation process (see Figure 9).




Figure 9. Completing the Driver Setup

After the dongle driver installation completes, the **ADI Power Studio Setup: Completed** dialog box shows the installation as completed. At this stage, the **ADI Power Studio®** GUI software is fully installed and ready to use.

Click the **Close** button to close the **ADI Power Studio Setup: Completed** dialog box (see Figure 10).




Figure 10. Closing the ADI Power Studio Setup: Completed Dialog Box

SETTING UP THE HARDWARE

The [ADI Power Studio](#) GUI gives the user full control to configure the sequencing and monitoring of a power system with up to 10 power rails on a single [ADM1260](#) device or up to 40 rails when using four [ADM1260](#) devices connected together on the high speed ICB. To control more than one [ADM1260](#), each device must have a unique SMBus address set up for the [ADI Power Studio](#) GUI to detect it.

Refer to the [EVAL-ADM1260EBZ](#) user guide and the [ADM1260](#) data sheet for complete instructions on the following actions:

- Connecting the [USB-SDP-CABLEZ](#) dongle for communication between the [ADI Power Studio](#) GUI software and the [ADM1260](#) devices.
- Configuring and powering up a single evaluation board or multiple evaluation boards.
- Setting up SMBus addressing.
- Configuring margining.
- Adjusting the on-board power rails to specific voltages.

LAUNCHING THE ADI POWER STUDIO GUI

To launch the [ADI Power Studio](#) GUI software, navigate to the Windows® programs menu and scroll to the **Analog Devices** folder. Click the **Analog Devices** folder to open it and display the software applications. Click the [ADI Power Studio v1.3.4.1](#) folder and click **ADI Power Studio** to launch the application, as shown in Figure 11.




Figure 11. Opening the *ADI Power Studio* Software

GUI OPERATIONAL MODES

The [ADI Power Studio](#) GUI can start in two operational modes, depending on whether or not the [USB-SDP-CABLEZ](#) dongle and the associated [ADM1260](#) evaluation board are connected to the computer workstation running the GUI. Choose from one of the following modes:

- Offline mode. The [ADI Power Studio](#) GUI defaults to offline mode if the [ADM1260](#) is not connected or detected for any reason.
- Online mode. The [ADI Power Studio](#) GUI starts in online mode if the [ADM1260](#) is connected and detected.

THE ADI POWER STUDIO GUI WELCOME TAB

The [ADI Power Studio](#) GUI first launches the **Welcome** tab, as shown in Figure 12.




Figure 12. *ADI Power Studio* Welcome Tab

If a dongle and the associated **ADM1260** devices are connected, the **ADI Power Studio** GUI automatically detects the **ADM1260** dongle and the **ADM1260** devices during startup.

When connected hardware is detected, a **Select a dongle to connect** dialog box appears, showing the following:

- Which dongles are connected to the computer and the associated addresses of the dongles.
- Which **ADM1260** devices are connected with the associated SMBus address and device ID.

In the example shown in Figure 13, there is a single dongle connected to three **ADM1260** devices. After the addresses and device ID values are verified, click **OK**.




Figure 13. **Select a dongle to connect** Dialog Box

14380-012

HOW TO GENERATE A BASIC SEQUENCING PROJECT

The following sections describe an example that assumes the system is in online mode and uses three [ADM1260](#) devices.

STARTING A NEW SEQUENCING PROJECT

To start a new sequencing project, click the **New Project** button in the **Welcome** tab (see Figure 14).




Figure 14. Starting a New Project

A **Project** tab then appears, displaying the available **ADM1260** devices that are connected to the system.

This tab is shown in Figure 15.




Figure 15. ADI Power Studio **Project** Tab

14380-014




Figure 16. ADI Power Studio Project Drop-Down Menu

Saving a Project

Save the project periodically as more settings are configured. Saving can be done by selecting **Save Project** under the **Project** drop-down menu (see Figure 16).

Choose a location for the project file, enter the file name, and click **Save** (see Figure 17).




Figure 17. Saving the Project File

CONFIGURING THE ADM1260 HARDWARE

Adding Supply Rails

The **ADI Power Studio** GUI allows the user to configure the **ADM1260** devices in the **Graphical View**, by entering the

supply rails as a power tree/block diagram or by configuring individual pins using the **Table View** option (see Figure 19).

Go to the **Supply Rails** tab by clicking the **Next** button shown in the **Project** tab (see Figure 18).




Figure 18. Device List in the **Project** Tab

14380-017

After the **Next** button is clicked, the **Supply Rails** tab appears. The **Supply Rails** tab defaults to **Graphical View**. However, the user can change to **Table View** by clicking on the **Table View** button.

In the **Supply Rail** tab click the **+ Add- 1** button to add rails, as shown in Figure 19.




Figure 19. Adding Rails in the **Supply Rails** Tab

Each time the + **Add- 1** button is clicked, a graphical representation of each added supply rail appears sequentially with the associated control (output) and monitoring (input) ports.

After clicking on the + **Add- 1** button 10 times for each connected board, the **Supply Rails** tab shows the supply rails shown in Figure 20.

Adding the rails allows the **ADI Power Studio** GUI to configure 10 rails on each of the three **ADM1260** devices.

The scroll bar is required to scroll through all the rails, shown in Figure 21




Figure 20. Adding Inputs and Outputs in the Supply Rail Tab




Figure 21. Using the Scroll Bar to View the Supply Rails

CONTROL AND MONITORING ASSIGNMENT

Assigning the Output Ports

After the rails are added, assign the outputs that enable or disable the supply rails. To set up an output for a given rail, click the field to the left of the rail; then, a drop-down menu appears, displaying all the available PDOx output signals.

Each PDOx output signal has an associated port identifier and address in hexadecimal format (for example, PDO1@34) to identify the [ADM1260](#) device to which the PDOx output pin belongs (see Figure 22).




Figure 22. Assigning the Output Ports in the **Supply Rails** Tab

14360-022

Refer to the [EVAL-ADM1260EBZ](#) evaluation board user guide to determine which PDOx output signals control each of the supply rails. Assign each of the voltage rails to correspond with the PDOx output signals on the [ADM1260](#) evaluation board schematic.

Assign all the PDOx output signals by clicking on the PDOx output field for each rail and setting them to the corresponding enable signal of the [ADM1260](#) evaluation board.

When all the outputs are assigned, the supply rails appear as shown in Figure 23.




Figure 23. Assigning the Supply Rail Outputs

Assigning the Input Ports

Next, assign the input ports, which monitor the output voltages of the supply rails. To assign an input for any given rail, click the field to the right of the rail and a drop-down menu displays the available monitoring channels.

Each monitor has an associated port identifier and address in hexadecimal format (for example, VX1@34) to identify which [ADM1260](#) device to which the input channel belongs (see Figure 24).




Figure 24. Assigning the Input Ports in the **Supply Rails** Tab

14380-024

Refer to the [EVAL-ADM1260EBZ](#) evaluation board user guide to determine which monitor channel connects to each of the supply rails. Assign each of the supply rails to correspond with the monitor channels on the [ADM1260](#) evaluation board schematic.

Assign the inputs for the supply rails by clicking on the input field (VXx, VPx, or VH) for each supply rail and set them to the corresponding inputs of the [ADM1260](#) evaluation board.

When all of the inputs are assigned, the supply rails appear as shown in Figure 25.




Figure 25. Assigning the Supply Rail Inputs

CONFIGURING THE OUTPUTS AND INPUTS OF THE ADM1260

Configuring the Output Ports

To control the supply rails, configure the outputs so they operate under sequencer control and have the correct pull-up or pull-down topology.

To configure a supply rail, click the desired rail and a **Properties** window appears on the right side of the GUI, shown in Figure 26.

Select several supply rails by holding the Control key and click the desired rails to speed up the editing process.




Figure 26. Opening the Properties Window

14360-026

PROPERTIES

Setting the Output Data Property

Move the cursor to the **Control - PDO > Output Data** field and click on it. A drop-down menu option appears.

The user can select from the following modes, shown in Figure 27: **Disabled**, **weak pull-down**; **Under Sequence Engine Control**; **Set Low**; or **Set High**.

Select all the supply rails, click open the **Output Data** drop-down menu, and select **Under Sequence Engine Control**. This makes changes to all the supply rails simultaneously.




Figure 27. Output Data Modes

Setting the Pull-Up Property

Move the cursor to the **Control - PDO > Pull-up** field and click on it. A drop-down menu option appears, shown in Figure 28.

Select from the following modes, shown in Figure 28: **None**; **Charge Pump**; **Weak pull-up to VP1**; **Strong pull-up to VP1**, **Weak pull-up to VP2**; **Strong pull-up to VP2**; **Weak pull-up to VP3**; **Strong pull-up to VP3**; **Weak pull-up to VP4**; **Strong pull-up to VP4**; **Weak pull-up to VDDCAP**; and **Strong pull-up to VDDCAP**.

To configure the **Pull-up** settings, only supply rails with PDO1@34 to PDO6@34 and PDO7@34 to PDO10@34, can be selected as groups for editing since the two groups are not identical in functionality.

Refer to the [ADM1260](#) data sheet for more details about the PDOx output signals.

Select **Supply 1** to **Supply 6** for each [ADM1260](#) device and set the **Pull-up** mode to **Strong pull-up to VDDCAP**, shown in Figure 28.

Select **Supply 7** to **Supply 10** for each [ADM1260](#) device and set the **Pull-up** mode to **Strong pull-up to VDDCAP**, shown in Figure 29.




Figure 28. Setting the **Pull-up** Property for **Supply 1** to **Supply 6**




Figure 29. Setting the **Pull-up** Property for **Supply 7** to **Supply 10**

CONFIGURING THE INPUT PORTS

The input ports must be configured to match the voltage range of the supply rails and must be monitored. The warning and fault thresholds must also be set to the level required by the ADM1260 evaluation board or operating system.

The VH, VPx, and VXx pins share many parameters, however, there are some differences in functionality. Refer to the ADM1260 data sheet for more details.

There are many settings available for each VH, VPx, and VXx inputs, which are displayed in the **Properties** window, shown in Figure 26.

To configure a supply rail, click it and the **Properties** window appears on the right side of the software window.

SETTING THE VXx MONITOR CHANNELS

Select **Supply 1** to **Supply 5** for each ADM1260 device and set the following properties in the **Properties** window.

Setting the Rail Property

To set the **Nominal Voltage**, go to **Rail > Nominal Voltage** and type in the voltage value of the selected rail. Enter the value **1.000 Volts**, shown in Figure 30.



Figure 30. Setting the **Nominal Voltage** Property

Setting the Monitor - ADC_INPUT Properties

To set the **ADC Warning Type** property, click the **ADC Warning Type** drop-down menu under the **Monitor - ADC_INPUT** menu. Select either the **OV Warning** or the **UV Warning** option for the analog-to-digital converter (ADC). Click the arrow to open the drop-down menu and select **OV Warning**, shown in Figure 31.




Figure 31. Setting the **ADC Warning Type** Property

To set the **Enabled** property, click the **Enabled** drop-down menu under the **Monitor - ADC_INPUT** menu. Select either **Enabled** or **Disabled**. Click the arrow to open the drop-down menu and select **Enabled**, shown in Figure 32.




Figure 32. Setting the **Enabled** Property

To set the **OV Warning Level** property, click the **OV Warning Level** drop-down menu under the **Monitor - ADC_INPUT** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **OV Warning Level** to **1.205 Volts**, shown in Figure 33.




Figure 33. Setting the **OV Warning Level** Property

Setting the Monitor - PAD Property

To set the **Mode** property, click the **Mode** drop-down menu under the **Monitor - PAD** menu. Select from the following modes: **SFD Fault**; **GPI Fault**; **GPI Fault & SFD Warning**; or **None (ADC Input)**. Select the **SFD Fault** option, shown in Figure 34.




Figure 34. Setting the **Mode** Property

Setting the Monitor - SUPPLY_MONITOR Properties

To set the **Fault Glitch Filter** property, click the **Fault Glitch Filter** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Select from a range of **0uS** to **100uS**; select **20uS**, shown in Figure 35.




Figure 35. Setting the **Fault Glitch Filter** Property

To set the **Fault Type** property, click the **Fault Type** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Select from the following fault types: **Over Voltage**; **Out of Window**; **Under Voltage**; or **Off**. Select **Out of Window**, shown in Figure 36.




Figure 36. Setting the **Fault Type** Property

To set the **OV Fault Hysteresis** property, click the **OV Fault Hysteresis** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **OV Fault Hysteresis** property to **0.050 Volts**, shown in Figure 37.




Figure 37. Setting the **OV Fault Hysteresis** Property

To set the **OV Fault Level** property, click the **OV Fault Level** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **OV Fault Level** property to **1.355 Volts**, shown in Figure 38.




Figure 38. Setting the **OV Fault Level** Property

To set the **UV Fault Hysteresis** property, click the **UV Fault Hysteresis** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **UV Fault Hysteresis** property to **0.050 Volts**, shown in Figure 39.




Figure 39. Setting the **UV Fault Hysteresis** Property

To set the **UV Fault Level** property, click the **UV Fault Level** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **UV Fault Level** property to **0.727 Volts**, shown in Figure 40.




Figure 40. Setting the **UV Fault Level** Property

SETTING THE VPXx MONITOR CHANNELS

Select **Supply 6** to **Supply 9** for each **ADM1260** device and set the following properties in the **Properties** window.

Setting the Rail Property

To set the **Nominal Voltage**, go to **Rail > Nominal Voltage** and type in the voltage value of the selected rail. Enter the value **3.300 Volts**, shown in Figure 41.



Figure 41. Setting the **Nominal Voltage** Property

Setting the Monitor - ADC_INPUT Properties

To set the **ADC Warning Type** property, click the **ADC Warning Type** drop-down menu under the **Monitor - ADC_INPUT** menu. Select either the **OV Warning** or the **UV Warning** option. Click the arrow to open the drop-down menu and select **OV Warning**, shown in Figure 42.




Figure 42. Setting the **ADC Warning Type** Property

To set the **Enabled** property, click the **Enabled** drop-down menu under the **Monitor - ADC_INPUT** menu. Select either **Enabled** or **Disabled**. Click the arrow to open the drop-down menu and select **Enabled**, shown in Figure 43.




Figure 43. Setting the **Enabled** Property

To set the **OV Warning Level** property, click the **OV Warning Level** drop-down menu under the **Monitor - ADC_INPUT** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **OV Warning Level** to **3.890 Volts**, shown in Figure 44.




Figure 44. Setting the **OV Warning Level** Property

Setting the Monitor - SUPPLY_MONITOR Properties

To set the **Range** property, click the **Range** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Select from the following voltage ranges: **2.5V – 6.0V**; **1.25V – 3V**; or **0.537V - 1.375V**. Click the arrow to open the drop down menu and select **2.5V - 6.0V**, shown in Figure 45.




Figure 45. Setting the **Range** Property

To set the **Fault Glitch Filter** property, click the **Fault Glitch Filter** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Select from a range of **0uS** to **100uS**; select **20uS**, shown in Figure 46.




Figure 46. Setting the **Fault Glitch Filter** Property

To set the **Fault Type** property, click the **Fault Type** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Select from the following fault types: **Over Voltage**; **Out of Window**; **Under Voltage**; or **Off**. Select **Out of Window**, shown in Figure 47.




Figure 47. Setting the **Fault Type** Property

To set the **OV Fault Hysteresis** property, click the **OV Fault Hysteresis** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. **Set the OV Fault Hysteresis** property to **0.220 Volts**, shown in Figure 48.




Figure 48. Setting the **OV Fault Hysteresis** Property

To set the **OV Fault Level** property, click the **OV Fault Level** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. **Set the OV Fault Level** property to **4.298 Volts**, shown in Figure 49.




Figure 49. Setting the **OV Fault Level** Property

To set the **UV Fault Hysteresis** property, click the **UV Fault Hysteresis** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. **Set the UV Fault Hysteresis** property to **0.220 Volts**, shown in Figure 50.




Figure 50. Setting the **UV Fault Hysteresis** Property

To set the **UV Fault Level** property, click the **UV Fault Level** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **UV Fault Level** property to **2.500 Volts**, shown in Figure 51.




Figure 51. Setting the **UV Fault Level** Property

SETTING THE VH MONITOR CHANNELS

Select **Supply 10** for each **ADM1260** device and set the following properties in the **Properties** window.

Setting the Rail Property

To set the **Nominal Voltage**, go to **Rail > Nominal Voltage** and type in the voltage value of the selected rail. Enter the value **12.000 Volts**, shown in Figure 52.



Figure 52. Setting the **Nominal Voltage** Property

Setting the Monitor - ADC_INPUT Properties

To set the **ADC Warning Type** property, click the **ADC Warning Type** drop-down menu under the **Monitor - ADC_INPUT** menu. Select either the **OV Warning** or the **UV Warning** option. Click the arrow to open the drop-down menu and select **OV Warning**, shown in Figure 53.




Figure 53. Setting the **ADC Warning Type** Property

To set the **Enabled** property, click the **Enabled** drop-down menu under the **Monitor - ADC_INPUT** menu. Select either **Enabled** or **Disabled**. Click the arrow to open the drop-down menu and select **Enabled**, shown in Figure 54.




Figure 54. Setting the **Enabled** Property

To set the **OV Warning Level** property, click the **OV Warning Level** drop-down menu under the **Monitor - ADC_INPUT** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **OV Warning Level** to **13.877 Volts**, shown in Figure 55.




Figure 55. Setting the **OV Warning Level** Property

Setting the Monitor - SUPPLY_MONITOR Properties

To set the **Range** property, click the **Range** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Select from the following voltage ranges: : **2.5V - 6.0V** or **6.0V - 14.4V**. Click the arrow to open the drop down menu and select **6.0V - 14.4V**, shown in Figure 56.




Figure 56. Setting the **Range** Property

To set the **Fault Glitch Filter** property, click the **Fault Glitch Filter** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Select from a range of **0uS** to **100uS**; select **100uS**, shown in Figure 57.




Figure 57. Setting the **Fault Glitch Filter** Property

To set the **Fault Type** property, click the **Fault Type** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Select from the following fault types: **Over Voltage**; **Out of Window**; **Under Voltage**; or **Off**. Select **Out of Window**, shown in Figure 58.




Figure 58. Setting the **Fault Type** Property

To set the **OV Fault Hysteresis** property, click the **OV Fault Hysteresis** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **OV Fault Hysteresis** property to **0.264 Volts**, shown in Figure 59.




Figure 59. Setting the **OV Fault Hysteresis** Property

To set the **OV Fault Level** property, click the **OV Fault Level** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by typing the value in the field or using the slider tool. Set the **OV Fault Level** property to **14.071 Volts**, shown in Figure 60.




Figure 60. Setting the **OV Fault Level** Property

To set the **UV Fault Hysteresis** property, click the **UV Fault Hysteresis** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by by typing the value in the field or using the slider tool. Set the **UV Fault Hysteresis** property to **0.264V Volts**, shown in Figure 61.




Figure 61. Setting the **UV Fault Hysteresis** Property

To set the **UV Fault Level** property, click the **UV Fault Level** drop-down menu under the **Monitor - SUPPLY_MONITOR** menu. Enter the voltage value by by typing the value in the field or using the slider tool. Set the **UV Fault Level** property to **8.009 Volts**, shown in Figure 62.




Figure 62. Setting the **UV Fault Level** Property

SETTING UP A SEQUENCE

Using the Sequence Wizard

To set a sequence for the supply rails, click the **Next** button in the **Supply Rails** tab to open the **Sequence Wizard Options** tab, shown in Figure 63.

After clicking the **Next** button, the **Sequence Wizard Options** tab appears (see Figure 64).




Figure 63. Opening the **Sequence Wizard Options** Tab




Figure 64. The **Sequence Wizard Options** Tab

The **Sequence Wizard Options** tab is where the overall order and timing of the sequence is set. The sequence wizard is primarily used to accelerate the process of configuring the sequence. However, the user has full control over the timing and order of the sequence in detail when editing the individual sequencing states.

Supply Order

The order of how the supplies are sequenced when using the sequence wizard depends on if the supply rails are entered graphically (see Figure 63) or in tabular form (see Figure 64). The order of the sequenced supplies can be changed by typing a new value into the **Supply Order** column, shown in Figure 65. In the sequential order, Supply 1 powers up first followed by Supply 2, Supply 3, and so on.




Figure 65. Sequential Example of the Supply Order

Supply Name

The **Supply Name** column displays the names of the supply rails (see Figure 64).

Supply Monitor

The **Supply Monitor** column displays the values and names of the monitor (input) channels (see Figure 64).

Supply Control

The **Supply Control** column displays the values and names of the control (input) ports (see Figure 64).

Options

The **Options** window sets the **Fault Options** and **Timing Options** for the sequence wizard (see Figure 66).




Figure 66. Options Window

Fault Options

- **Single Fault State**—This option lets the user configure the sequencer to allow only a single fault state.
- **Multiple Fault States**— This option lets the user configure the sequencer to allow multiple fault states.
- **Disable all Rails in the fault states**—When this option is checked, the sequencer disables all the rails if any fault occurs during a sequence. If this option is not selected, the sequencer states configure to not disable any rails during a fault. However, individual states can be edited later in the **Build Sequence** tab (see Figure 76) to disable any combination of rails as required.

Timing Options

- **Enable Timeout for each state**—When this option is checked, the sequencer enables a timeout for each state. In most cases, timeouts are required for most or all states. However, if this option is not checked, some states do not have timeouts. Timeouts can be added later to any of the selected states in the **Build Sequence** tab (see Figure 76).
- **Timeout after (ms)**—This allows the user to set the time it takes for the timeout to occur. In general, the timeout value must be greater than the transition time or else the sequencer jumps to the fault state and prevents any other sequencing states to complete.
- **Transitions after voltage is stable for (ms)**—This option allows the user to set the time the sequencer waits for the rail being monitored to become stable. If the overvoltage (OV) and undervoltage (UV) condition is met, the sequencer goes to the next state assigned in the sequence engine. This time must always be less than the **Timeout after (ms)** value or else the sequencer jumps to the fault state and prevents any other sequencing states to complete.

Configuring the Fault Options

Set the **Fault Options** to **Single Fault State** and check the **Disable all Rails in the fault states** checkbox, shown in Figure 67.




Figure 67. Configuring the Fault Options

Configuring the Timing Options

Set the **Timeout after (ms)** button to **400 ms** and click the **Update** button, shown in Figure 68 and Figure 69.




Figure 68. Setting the **Timeout after (ms)** Option




Figure 69. Click the **Update** Button to Update the **Timeout after (ms)** Option

After clicking the **Update** button, a dialog box appears asking **Do you want to update all timeout settings?** Click **Yes** to accept the changes (see Figure 70).




Figure 70. Updating the Timeout Settings

Set the **Transition after voltage is stable for (ms)** to **100 ms**, shown in Figure 71.




Figure 71. Setting the **Transition after voltage is stable for (ms)** Option

Click on the **Update** button, shown in Figure 72.




Figure 72. Updating the **Transition after Voltage is stable for (ms)** Option

After clicking the **Update** button, a dialog box appears, asking **Do you want to update all transition time settings?** (see Figure 73). Click **Yes** to accept the changes.




Figure 73. Updating the Transition Time Settings

Generating the Sequence

To generate the sequence click the **Generate Sequence** button, shown in Figure 74.




Figure 74. Generating the Sequence

After clicking the **Generate Sequence** button, a dialog box appears, asking, **Do you want to clear existing sequence and create a new one?**, shown in Figure 75. Click **Yes** to accept the changes.




Figure 75. Clearing an Existing Sequence and Creating a New Sequence

Once the changes to the sequence are accepted, the **Build Sequence** tab opens the sequencing states, shown in Figure 76. The sequence wizard generates all the rail states based on the initial supply rails diagram and the property values set for each rail, shown in Figure 53 to Figure 55.




Figure 76. Display of a Generated Sequence in the **Build Sequence** Tab

Running the Sequence

Click the **Play** button to start the sequence, as shown in Figure 77.

Sequence and State Configuration



Figure 77. Beginning the Sequence

Since this is the first time the sequence is starting, the **ADI Power Studio** GUI must compile the sequence to program it into the **ADM1260** devices. The **ADI Power Studio** GUI shows the sequence being compiled in the lower left corner of the window, as shown in Figure 78



Figure 78. Compiling Sequence Progress

Once the sequence is compiled, the **ADI Power Studio** GUI programs the registers, the user memory, and rail sequence into the **ADM1260** devices at the corresponding addresses, shown in Figure 79.



Figure 79. EEPROM Programming Progress

After all the **ADM1260** devices are successfully programmed, the sequence runs and the rail states advance sequentially, shown in Figure 80.




Figure 80. Current State of the Sequence Engine

If all the rails power up correctly and fall within the range of the UV and OV fault thresholds, the sequence advances and jumps to the **Power Ok** state, as shown in Figure 81.



Figure 81. Sequence Jumps to **Power Ok** State

If any of the rails do not power up correctly or fall outside the range of the UV and OV fault thresholds, the sequence jumps to the **Power Failure** state, as shown in Figure 82.




Figure 82. Sequence Jumps to **Power Failure** State

Monitoring the Power Rails

How to Monitor the Power Rails

The user can monitor the power rails in several ways. One method is to use the **Pin Status Monitor** tab (see Figure 85), that displays all the selected rails as a plot and at real-time voltage readings from the ADCs of the **ADM1260** devices.

The other method is to use the **Rail Status Monitor** tab (see Figure 87), that displays the status of all the rails in either graphical or table form.

Using the Pin Status Monitor

To open the **Pin Status Monitor** window, click the **Monitor** drop-down menu and click the **Pin Status** option, shown in Figure 83. The **Pin Status** window then appears.

Click the **Read** button (see Figure 84) to display the ADC values of the power rails as a voltage plot over time, shown in Figure 85.




Figure 83. Selecting the **Pin Status** Option from the Monitor Drop-Down Menu




Figure 84. Click Read to Open the Voltage Plot




Figure 85. Description of the Pin Status Monitor Tab Components

Using the Rail Status Monitor

To open the **Rail Status Monitor** window, click the **Monitor** menu and click the **Rail Status** option, shown in Figure 86. After clicking the **Rail Status** option, the **Rail Status Monitor** tab appears, shown in Figure 87.

The **Rails Status Monitor** tab defaults to the **Graphical View**, however, the **Table View** can be selected by clicking the **Table View** button (See Figure 88).




Figure 86. Selecting the **Rail Status** Option from the Monitor Drop-Down Menu




Figure 87. **Graphic View** of the **Rail Status Monitor** Tab




Figure 88. Table View of the Rail Status Monitor Tab

USING THE BLACK BOX

HOW TO ADD BLACK BOX FUNCTIONALITY

Once sequencing is completed to the point where all rails are configured to power up and can be monitored using the [ADI Power Studio GUI](#), the black box can be enabled to diagnose the system if a fault occurs.

To edit the sequence, stop the sequence by clicking the **Stop** button in the **Build Sequence** tab (see Figure 89).

Once the sequence stops, the states can be edited to add the black box function.

A black box write can be added to any of the states in the sequence so that once the sequence jumps to the black box enabled state, a black box write occurs.

For this example, the black box write is added to the **Power Failure** state so that if a fault occurs with any of the rails, the sequence jumps to the **Power Failure** state and writes to the black box. To add the black box write to the **Power Failure** state, use the scroll bar in the state editing window to scroll down to the **Power Failure** state and click it to select it (see Figure 90).




Figure 89. Stopping the Sequence

14386-101




Figure 90. Selecting the Power Failure State

14386-102

Click to the left of the selected state to add the black box write. A marker appears showing the black box write is added to the state, shown in Figure 91.




Figure 91. Adding a Black Box Write to the **Power Failure** State

HOW TO USE THE BLACK BOX

Once the black box write is added to the **Power Failure** state, recompile the sequence and update the **ADM1260** with the new sequence. Click the **Play** button to start the sequence (see Figure 92).

Sequence and State Configuration



Figure 92. Recompile and Start the New Sequence

The **ADI Power Studio** GUI compiles the new sequence and updates the memory contents of the **ADM1260** with the new sequence. After this, the sequence runs and the supply fault detectors and the ADC monitor for faults and warnings.

To generate a fault so the sequence jumps to the **Power Failure** state and writes to the black box, one of the supply rails can be adjusted to create either an OV or UV condition.

Increase the output of the VP4 supply rail on the **ADM1260** at VP4@34 to create an OV fault. To trigger an OV event, turn the on-board potentiometer on the VP4 supply rail clockwise. The supply fault detector for the VP4 supply rail then detects the supply is overvoltage and causes the sequence to jump to the **Power Failure** state and write to the black box.

The **ADI Power Studio** GUI shows the sequence jump to the **Power Failure** state, shown in Figure 93.




Figure 93. The Sequence Jumps to the **Power Failure** State

Once the sequence jumps to the **Power Failure** state, the black box contains a list of what faults occur. To view the contents of the black box, click on the **Monitor** drop-down menu and select the **BlackBox** option (see Figure 94).



Figure 94. Selecting the **BlackBox** Option

After selecting the **BlackBox** option, the **BlackBox Monitor** tab appears, shown in Figure 95.

Click the **Read** button to view the contents of the black box in the **ADI Power Studio** GUI. Once the **ADI Power Studio** GUI reads the black box contents, the black box readings, shown in Figure 96, appear in the **BlackBox Monitor** tab.

The **BlackBox Monitor** tab shows the contents of the black box and what the **Exit State**, **Exit Condition**, and **Trigger Sources** are for any faults or warnings that occur.




Figure 95. Click the Read Button to View the Black Box Contents




Figure 96. Contents of the Black Box

BLACK BOX VIEWING OPTIONS

There are several different ways to view the black box, depending on how many ADM1260 devices are connected together.

Click the **System Black Box** drop-down menu, shown in Figure 97 and Figure 98, showing options to view the black box from all the ADM1260 devices connected to the system or ADM1260 individual devices.

Select from the following viewing options:

- **System Black Box.** This displays all of the ADM1260 devices connected on the ICB (see Figure 97).




Figure 97. Viewing All Connected ADM1260 Devices

- **ADM1260@(n).** This displays only a single ADM1260 at the listed address (see Figure 98).




Figure 98. Selecting a Single ADM1260 Device to View

BLACK BOX ERASE FUNCTION

To see if there are any new contents in the black box, click the **Erase** button to clear the contents in the **BlackBox Monitor** tab (see Figure 99).



Figure 99. Erasing the Contents in the BlackBox Monitor Tab

USING THE REGISTER VIEW

HOW TO VIEW THE ADM1260 REGISTERS

The ADI Power Studio GUI can be used to view the contents of all of the ADM1260 registers for all devices connected to the system.

View the registers of the ADM1260, click the Register View menu option and the Register tab appears, displaying the register contents of the ADM1260 devices (see Figure 100).




Figure 100. Viewing the ADM1260 Registers

14380-112

PIN SETTINGS

The sequencing example described shows how to configure the basic pin settings for the rails using the **Supply Rails** tab. The user can also configure the pin settings for a given sequencing design by using the **Pin Settings** tab. The **Pin Settings** tab gives more control over the various pin functions and configurations.

To open the **Pin Settings** tab, click on the **Hardware Configure** drop-down menu and select **Pin Settings** (see Figure 101).




Figure 101. Opening the **Pin Settings** Tab

After the selecting **Pin Settings**, the **Pin Settings** tab opens, shown in Figure 102.




Figure 102. The **Pin Settings** Tab

PIN SETTINGS VIEW

The tab can also change to display only the pins of interest by clicking on the **Settings View** drop-down menu and selecting either **All Pins**, **Supply Pins**, **ADC Input Pins**, **Digital Output Pins**, **Digital Input Pins**, or **DAC Pins** (see Figure 103).




Figure 103. The **Settings View** Drop-Down Menu

Graphic View

The **Pin Settings** tab can operate in either **Table View** (default) or **Graphic View**. To switch to **Graphic View**, click the **Graphic View** button (see Figure 104).



Figure 104. Changing the **Pin Settings** Tab View to **Graphic View**

The **Pin Settings** tab then appears in **Graphic View**, shown in Figure 105.




Figure 105. **Graphic View** of the **Pin Settings** Tab

ESD Caution
ESD (electrostatic discharge) sensitive device. Charged devices and circuit boards can discharge without detection. Although this product features patented or proprietary protection circuitry, damage may occur on devices subjected to high energy ESD. Therefore, proper ESD precautions should be taken to avoid performance degradation or loss of functionality.

Legal Terms and Conditions
 Information furnished by Analog Devices is believed to be accurate and reliable. However, no responsibility is assumed by Analog Devices for its use, nor for any infringements of patents or other rights of third parties that may result from its use. No license is granted by implication or otherwise under any patent or patent rights of Analog Devices. Trademarks and registered trademarks are the property of their respective owners. Information contained within this document is subject to change without notice. Software or hardware provided by Analog Devices may not be disassembled, decompiled or reverse engineered. Analog Devices' standard terms and conditions for products purchased from Analog Devices can be found at: http://www.analog.com/en/content/analog_devices_terms_and_conditions/fca.html.

©2016 Analog Devices, Inc. All rights reserved. Trademarks and registered trademarks are the property of their respective owners. UG14360-0-4/16(0)



www.analog.com